

RECEIVED
FROM
DAVE LIND
(619) 755-6117

54L

.10

Installation of canopy hinges:

- (a) Slightly notch canopy rail and longerons (abt. .15 total)
- (b) Bond one half of each hinge on a length of aluminum extrusion, carefully aligning both pieces to each other with a straight edge.
- (c) Flex to longeron. When cured break loose from extrusion.
- Spread flex on canopy... (d) ~~Flex~~ ^{Spread} canopy rail surface and other half of hinge; place canopy framework on fuselage using a small piece of foam rubber or other similar item to insure good contact against upper half of hinge; cure. Drill holes, install bolts.

