



EZ Speed Brake Actuator  
Mounting Details Rev#0  
Wayne Lanza 7/93  
no scale sheet 2 of 3

LB19 shown in open position

For more information contact:  
Wayne Lanza  
9425 Honeysuckle Dr.  
Sebastian, Fla. 32976  
(407) 664-9239

Note 'Reciever' in Mounting Bracket to take actuator loads when speed brake is extended. The compressed state, as shown, is to be typical when the brake is retracted.

